


**Fit middle screen first ,  
wind top screen down and  
bottom screen up to meet .  
  
Reverse to access middle  
screen .**

AW31

3 X PZX Type 1 Vertical  
Adjustable Video Wall



**Winder to wind screens up / down .**

**Winder to wind screens up / down .**