



### INSPECT THE UNIT BEFORE INSTALLING

**WARNING:** Watch for pinch points. Do not put your fingers between movable parts.

1. Carefully inspect the Unit for shipping damage. If any damage is apparent, call your carrier claims agent and do not continue with the installation until the carrier has reviewed the damage.


**NOTE:** Read all instructions before starting the installation.

2. Lay out components to ensure you have all the required parts before proceeding (see Parts on Page 2).

**CAUTION:** To prevent damage to the unit study all instructions and illustrations before you begin the installation. Failure to do so could render the Warranty for the unit and the equipment that attaches to it null and void. Pay particular attention to the "Warnings" displayed in these Instructions.

If you have any questions about the installation, contact Unicol

## Parts List and Step Guide



Assemble unit by following the steps above.

**WARNING:** Screens are heavy. We recommend a suitable hoist is used to lift the Screen when fitting to the vertical bars on the screen mount (Step 6).

These instructions are valid for all Axia Titan units except the Powa-Lift version. There are 2 different lengths of mast section and stand only models do not have castors fitted.

Cables are routed through mast section.

If you have any questions about the installation, contact Unicol  
+49 9131 940580-0 info@unicol.de www.unicol.de