



TETHERLOC ANTI-THEFT KIT

For Gyrolock GK1, 2 & 3

Ref: UNICOL

GT40

GT80

GT130

Add this easily fitted kit to your Gyrolock mount unit. Tough steel cable system blocks access to both projector and mount fixing screws in the ceiling, yet allows full movement of projector during set-up.

Current GAP adapter plates are designed ready to take the Tetherloc System, which works with most projector models listed. Long series cable versions also available.



Gyrolock Fixing Plate

① Fit Tetherloc fixing plate to Gyrolock fixing plate using the fastenings that hold the Gyrolock to the ceiling, wall, or desktop

④ Thread cut end of cable through retaining slots in security top plate

⑤ Slot lock cover into security top plate and lock to complete installation

② Fit Gyrolock Adapter Plate (GAP) to projector by screwing fixing screws through security block.

Fit Projector and GAP to Gyrolock.

③ Thread cable through security block

UGT1102